



See Different.

Manual Firmware Update Instruction


Note:

In order to update the firmware successfully, please keep the following precautions and inhibited points when it is in the update process.


a, Do not remove the battery; b, Do not take out the SD card; c, Do not remove/add power cords or any other cords; d, Do not uninstall the lens; e, Do not press any button; f, Do not cut off the power source.

Otherwise, the camera/lens will be damaged, and can't get back to normal.


1. Firstly please ensure the battery capacity is more than 50%, copy the 'firmware.bin' to SD card root directory. (Before V1.2-int version of firmware, please copy the firmware.bin file to the root directory of SD card under XIAOYI folder, if there is no XIAOYI folder please create it manually). Then insert the SD card into the camera.



2. Restart the camera, slide right on the Live View screen and switch to the 'MENU SETTING' screen, then slide up twice and click the 'Firmware Info' icon, as shown below:



3. Click the 'Firmware Info' icon, you can check the current firmware information as shown below:



4. Press the 'Q' and 'PLAYBACK' buttons on the 'Firmware Info' screen **at the same time**, then switch to the Factory Settings screen.



5. Select the 'Upgrade Camera Firmware' item, then it will pop up a dialog and select 'Yes', it will be successful after 12 seconds and will reboot automatically.

